


## ADAPT-Floor Pro DESIGN PROCESS




(a) DWG file imported into ADAPT-Modeler.






(i) Design Sections are generated automatically for **stress check**. Calculated stresses and compared with allowable values. Red lines (or broken lines) indicate regions where code values are exceeded.



(j) **Calculated stresses** for each Design Strip can be superimposed on the **allowable stress envelope**.



(k) Reinforcement for each design strip is automatically selected by the program and displayed, specifying the location, number and length of bars